


User Manual

JAXPETY




JAXPETY


You need

1

Tools required




A Phillips head screwdriver is required for the assembly of this product. (not included)
























2

1 person is needed







Hardware List

			
A1PC	B1PC	C1PC	D1PC
			
E1PC	F1PC	G1PC	H1PC
			
I1PC	J1PC	K1PC	L1PC
			
M1PC	N2PCS	O2PCS	P1PC
			
121PCS	221PCS	343PCS	421PCS
			
53.5X14mm6PCS			

PRODUCT ASSEMBLY



⚠ Check the package contents before getting started !

STEP 1





PRODUCT ASSEMBLY

STEP 2





PRODUCT ASSEMBLY

STEP 3





PRODUCT ASSEMBLY

STEP 4





PRODUCT ASSEMBLY

STEP 5





PRODUCT ASSEMBLY

STEP 6





PRODUCT ASSEMBLY

STEP 7





PRODUCT ASSEMBLY


STEP 8



STEP 9

**BEFORE CONNECTING THE UNIT TO A WALL ELECTRIC OUTLET**

Please carefully read and follow instructions and safety warnings in "Fireplace Homeowners Operating Manual" to operate your fireplace.

**WARNING**

IF THE INFORMATION IN THE FIREPLACE OPERATING MANUAL IS NOT FOLLOWED, AN ELECTRIC SHOCK OR FIRE MAY RESULT IN PROPERTY DAMAGE, PERSONAL INJURY, OR LOSS OF LIFE.

WARNING

Risk of death or serious injury. This unit must be placed against a fixed in place wall at least as tall as television.