


User Manual

JAXSUNNY



Model Number: HG61U0721
HG61T0720

JAXSUNNY

Dear Customer,

Thank you for your purchase.

JAXSUNNY is committed to providing affordable high-quality furniture worldwide.

Each piece is made with the respect for human and the environment.

Thousands of families use JAXSUNNY products as a home fashion.

When you receive the product, please make sure that all the parts are intact.

Then please browse the entire installation manual before assembly.

If problems occur unsatisfactorily as follows:

a.The outer box is damaged.

b.The product is damaged / bent / cracked while you open the box.

c.The parts / accessories / assembly tools are missing.

d.The product is hard to assemble.

e.The instructions are not clear and can not be referred to.

f.The product has functional problems.

g.Other aspects that you are not satisfied with.

Please do not hesitate to contact us for help (Be sure to mark the **SKU NUMBER**, e.g., HG91S0320, and the **TRACKING NUMBER**).


Our JAXSUNNY team with factory direct after-sales service will reply within 24 hours and will do our best to resolve the problem for you. Our services are available at any time.

Sincerely,
JAXSUNNY Team

JAXSUNNY,
for Home and Fashion!

You need

① Tools required




② 1 person is needed

















Technical Specifications

| | |
|----------|-----------------|
| Material | Metal + Plastic |
| Size | 560*740*15mm |



Hardware List

| | | | | | | | | | | | |
|---|---|------|---|---|------|---|---|------|---|---|------|
|  | A | 1PC |  | B | 4PCS |  | C | 4PCS |  | D | 5PCS |
|  | E | 4PCS |  | F | 1PC |  | G | 8PCS |  | H | 8PCS |
|  | I | 8PCS |  | J | 8PCS |  | K | 4PCS |  | L | 4PCS |
|  | M | 4PCS |  | N | 2PCS | | | | | | |

PRODUCT ASSEMBLY

! Check the package contents before getting started !

STEP 1

NOTE: When adding a panel, please check to make sure adjacent upper plastic joints are in different direction (curved line face inward and outward) as shown on below diagram.

FIGURE 1A







FIGURE 1B

The lower plastic joints must be always in the same direction with upper plastic joints.








PRODUCT ASSEMBLY

STEP 2



PRODUCT ASSEMBLY



STEP 3**STEP 4**

Locking Knob


TO SECURE GATE PANELS

Turn the knob counter clockwise until they are hand tight.

STEP 5


TO OPEN THE DOOR

1. Push the door release button backward.
 2. Lift the door panel upward.
 3. Swing door open and release button.
- Note: If you open the door past 90 degrees, it will stay open.



WALL MOUNTING

INSTALL WALL MOUNT BRACKETS TO WALL



- TO PREVENT SERIOUS INJURY OR DEATH, SECURELY INSTALL GATE AND USE ACCORDING TO MANUFACTURER' S INSTRUCTIONS.
- NEVER USE WITH A CHILD ABLE TO CLIMB OVER GATE OR DISLODGE/OPEN THE GATE.
- THIS PRODUCT WILL NOT NECESSARILY PREVENT ALL ACCIDENTS.
- KEEP AT LEAST 2 FEET FROM OPEN FLAME OR HEAT SOURCE.
- NEVER LEAVE CHILD UNATTENDED.
- USE ONLY WITH THE LOCKING/LATCHING MECHANISM SECURELY ENGAGED AND ON SIDE AWAY FROM CHILD.
- THIS PRODUCT INTENDED FOR USE WITH CHILDREN FROM 6 MONTHS UP TO 24 MONTHS OF AGE.
- HARDWARE IS INCLUDED FOR USE IN SOLID MATERIAL ONLY, SUCH AS WOOD OR METAL.



CHEKING HAZARD--Small parts, it is not for children under 3 years!