

User Manual






JAXPETY


You need








Hardware List



PRODUCT ASSEMBLY



Check the package contents before getting started!




WARNING

How To SEPARATE BALL BEARING SLIDE.


1) Pull toward arrow to open the slide until its stops and then flip it over.




2) Push plastic lever down and pull apart.



Cabinet member




Drawer member





Cam Lock **Fastening System**

This Cam Lock Fastening System will be used throughout the assembly process.



PRODUCT ASSEMBLY









PRODUCT ASSEMBLY


STEP 2












PRODUCT ASSEMBLY

STEP 3








JAXPETY JAXPETY


PRODUCT ASSEMBLY


STEP 4





STEP 5






Proper orlentation of CAM LOCK


JAXPETY


PRODUCT ASSEMBLY


STEP 6



STEP 7









PRODUCT ASSEMBLY

STEP 8





STEP 9

