


User Manual



Model Number: MR11M0189
MR11U0249



Dear Customer,

Thank you for your purchase.

RESHABLE is created to be the perfect starting spot for any barbers. Supplying top-quality barber supplies like barber chairs, salon stations, rolling makeup cases, styling drawer cabinets, hair tool holders, and more, we help people to keep their barber store running with the best equipment at the most reliable prices.

When you receive the product, please make sure that all the parts are intact. Then please browse the entire installation manual before assembly. If problems occur unsatisfactorily as follows:

a. The outer box is damaged.

b. The product is damaged/bent/cracked while you open the box.

c. The parts/accessories/assembly tools are missing.

d. The product is hard to assemble.

e. The instructions are not clear and can not be referred to.

f. The product has functional problems.

g. Other aspects that you are not satisfied with.

Please do not hesitate to contact us for help (Be sure to mark the SKU NUMBER, e.g., MR11R0246, and the TRACKING NUMBER). Our RESHABLE team with factory direct after-sales service will reply within 24 hours and do our best to resolve the problem for you. Our service is available at any time.

RESHABLE
for Profession and Creativity!

Sincerely,
RESHABLE Team


You need

① Tools required




A wrench & an allen key are required for the assembly of the product. (not included)














② 2 persons are needed




Technical Specifications	
Brand	RESHABLE
Material	Sponge + oak wood +PU leather
Style	contracted
Max weight capacity	330LBS







Hardware List


			
A 1PC	B 1PC	C 1PC	D 1PC
			
E 1PC	F 1PC	G 1PC	H 1PC
			
J 4PCS	K 6PCS	L 3PCS	M 1PC
			
N 4PCS			

PRODUCT ASSEMBLY

 Check the package contents before getting started !



STEP 1

			
A 1PC	B 1PC	C 1PC	N 4PCS




PRODUCT ASSEMBLY

STEP 2




PRODUCT ASSEMBLY

STEP 3






! **Note:** Please refer to the picture for the assembly direction of the foot lever. Do not install it in the wrong direction.



PRODUCT ASSEMBLY

STEP 4



Frequently Asked Questions

Q: How to maintain the backrest and seat daily?

A: The PU leather should be cleaned regularly. Spray a little of the leather care solution onto a sponge and then use the sponge to wipe the leather surfaces gently.

Q: How to maintain the hydraulic pump?

A: Keep the surfaces of the hydraulic pump (including the centre shaft) clean. Add some anti-rust oil to the cloth and then use the cloth to wipe the centre shaft gently.

Q: What is the weight limit for this chair?

A: 150KG (330LBS).

Q: Can the chair be rotated 360 degrees?

A: Yes.

Q: What if the chair is difficult to rotate?

A: Please check whether the foot bar is stepped to the lowest. Then step the foot bar several times to lift the chair. It will be solve.

Q: How to prevent the chair from leaning forward?

A: When you sit on the chair and lean all your weight forward deliberately, the chair will indeed tilt. So please notice this point: if both your feet are on the footrest, please sit backward as far as you can; meanwhile, please ask the barber or someone else to step the foot bar and set the chair to the lowest when the guest sitting on the chair is ready to stand up. (Note: please remind guests not to stand on the footrest with both feet, please put one foot on the ground first.)

Q: If the chair keeps tilting and cannot be righted, what should I do?

A: In this case, there may be something wrong with the installation. Please check whether the pump pin is completely inserted into the holes of the bottom tray.

Q: What should I do when the seat cannot be lifted or lowered normally?

A: The hydraulic pump may be broken. Please replace it.

Dear Customer, if you have any advice or questions on the installation or product after receiving, please give us feedback as soon as possible. We will provide you with professional guidance. Please feel free to use it.