
User Manual

Instruction for Assembly 8' * 10' Metal Shed



Missing Parts, Quality Problem, Questions on Assembly? Email: Hogyme.service@gmail.com Request will be replied in 24 hours.

Model Number: HG61S1295

HOGYME

HOGYME

Assembly Preparation

Owner's Manual

Please check local building codes regarding footings, location and other requirements before beginning construction.

Assembly instructions:

Reviewing all instructions and the appropriate information before you begin, make sure following the step sequence carefully for successful results.

Flooring base:

A good location for the storage building is a square and level area with good drainage. The base is not included in the kit which may need purchase separately or may construct a foundation and anchoring system of your own.

A strong plastic sheet (thickness: at least 150μ m) should be placed under the foundation to assist in reducing rising dampness from the soil, thus reducing condensation build up in the shed. Your storage building must be anchored to prevent wind damage. Once secured, it is highly recommended applying silicone along the inside of the base rail to minimize condensation.

Parts and Parts List:

Before you start, separate and identify all the parts and hardware to be sure that you have all the necessary parts for your building (refer to the Parts List Page).

If you find that a part is missing, please notify the seller within one week after receiving the product. Do not attempt to assemble the building if parts are missing because any building left partially assembled may be seriously damaged by light winds.

Tools you need:

(Please tear off the safety protection layer before the assembly, keep the part number label if needed)




Safety must be put in the No. 1 position:

- Select a dry and calm day for your assembly. Team works (Two or more people) are required during the assembly. It is also recommended to finish the assembly in a day to avoid damage to the product or missing of some small parts.
- 2. Wearing safety gloves, eye protection and long sleeves during the assembly to prevent injury. Pay attention to the sharp edge of some parts.
- 3. Children and pets are not allowed entering into the construction site.
- 4. Never concentrate your total weight on the roof of the building. When using a step ladder make sure that it is safe.


Care & Maintenance:

- 1. Keep the shed clean with soft cloth, use water if necessary.
- 2. Keep the door tracks clear of dirt and other stuff that prevent them from sliding easily.
- 3. Clean the snow with necessary tools to make sure it is safe to enter into.
- 4. The shed is not made for living but storing stuff.
- 5. Please add some oil on the top and bottom door sliding channel to make door slides smoothly.


Size:





Area of installation requirement:











Hardware List						
PART	NO.	Qty.	Box No.			
	G2	4	2/3			
	GB	2	2/3			
	GC	4	2/3			
Je se	GD	4	2/3			
	GE	2	2/3			
	GF	4	2/3			
<mail:< th=""><th>F1</th><th>490</th><th>2/3</th></mail:<>	F1	490	2/3			
	F2	98	2/3			
	F3	8	2/3			
For drilling	F4	1	2/3			
	S1	188	2/3			
	S2	430	2/3			
ج <u>ہ</u> ک	1	2	3/3			
۲ این <u>ه</u>	2	2	3/3			

PART	NO.	Qty.	Box No.
	3L&3R	2	3/3
÷ <u></u> ک	4L&4R	2	3/3
······································	5	1	3/3
	6	1	2/3
	7&8	2	3/3
	9&11	4	3/3
	22&23	4	3/3
<u>с</u> г	10L&10R	2	3/3
<u>с</u> г	24L&24R	2	3/3
	13&14	8	3/3
Г	15	2	1/3
r	16	2	1/3
F	17	2	1/3
г	18	2	1/3

- 6 -

PART Qty. NO. Box No. 19 2 2/3 20 2/3 2 4 21L 2 2/3 21R 2 2/3 . 1/3 25L 1 . • 25R 1 1/3 27 2 2/3 Γ B1&B2 4 3/3 ۰ ۰ 3/3 • • B3 4 2 1/3 P1 P1B 2 2/3 P2 2 2/3 P2A 2 2/3 7.

PART	NO.	Qty.	Box No.
	Р3	16	1/3
	Р5	6	2/3
	P6	4	2/3
	Ρ7	4	2/3
	P8	2	2/3
	D1	1	1/3
	D2	1	1/3

HOGYME

8 -




STEP 1

1	×	X2	2	×	X2
4L	~~~~>>	X1	4R	~>	X1
F1		X12			


PRODUCT ASSEMBLY

STEP 2





9



- 10 -

HOGYME


PRODUCT ASSEMBLY

STEP 3


F1		X2
----	--	----

PRODUCT ASSEMBLY


STEP 4



HOGYME



- 11 -



X4

PRODUCT ASSEMBLY

STEP 5

5	}	X1	F1	< 000()
	· · · · · · ·			v



The floor frame must be level and square or holes will not align.


(Notice: Measure the floor frame diagonally. When the diagonal measurements are equal, the floor frame is square.)


PRODUCT ASSEMBLY



Make the colored side of the steel plate outward.








PRODUCT ASSEMBLY


STEP 7

P3		X1	F1	X4
S2	0	X4		

PRODUCT ASSEMBLY

P2A		X1	F1	X3
S2	0	X3		






PRODUCT ASSEMBLY

STEP 9


P1B		X1	F1	X3
S2	0	X3		

PRODUCT ASSEMBLY

STEP **10**



- 18 -




- 17 -


PRODUCT ASSEMBLY

STEP 11

P1B		X1	F1	<mail:< th=""><th>X3</th></mail:<>	X3
S2	0	X3			

PRODUCT ASSEMBLY





PRODUCT ASSEMBLY


STEP 13

P3		X1	F1	X4
S2	0	X4		





STEP 14

22	 X2	23		X2
24L	 X1	24R	r	X1
F1	X3			










21 -

PRODUCT ASSEMBLY

STEP 15


9	 X2	10L	r	X1
10R	 X1	11		X2
F1	X3			

Put the side with fewer holes facing up




PRODUCT ASSEMBLY

STEP **16**





Put the side with fewer holes facing up.



PRODUCT ASSEMBLY STEP 17

0 X14 X14 S2 F1 Put the side with fewer holes facing up. 1 90° **2**x **2**x


PRODUCT ASSEMBLY


STEP 18

F1 .	X12	S2	0	X12	
------	-----	----	---	-----	--



Put the side with fewer holes facing up.





PRODUCT ASSEMBLY

STEP **19**

7	 X1	8	O	X1
G2	X4			



27 ·


PRODUCT ASSEMBLY

STEP **20**

6	J	X1	F1	X2
F4	4000000	X1		




The 2 screws fixed in this step need to be removed and reinstalled later in the following steps. There are not pre-drilled holes on part 7 and part 8, but they can be easily fixed with screws F1 or F4.



HOGYME




STEP **21**



PRODUCT ASSEMBLY






PRODUCT ASSEMBLY

STEP 23


P3		X1	F1	X15
S2	0	X15		

PRODUCT ASSEMBLY

STEP 24



32




- 31-

PRODUCT ASSEMBLY

STEP 25

P3		X1	F1	-	X15
S2	0	X15			




PRODUCT ASSEMBLY

P3		X3	F1		X36
S2	6	X36			
				3x S2x4 F1x4 C2x4 F1x4	

PRODUCT ASSEMBLY

STEP 27


P3		X1	F1	X15
S2	0	X15		



- 35

PRODUCT ASSEMBLY

P1	X2	F1		X16
F2	X2	S2	0	X20



PRODUCT ASSEMBLY


STEP 29


25L	ار د	X1	25R	:	X1
F1		X12	S2	0	X12

PRODUCT ASSEMBLY

STEP **30**

21L	X2	21R	X2
GF	X4	F2	X8





- 38 -

PRODUCT ASSEMBLY

STEP **31**

B1	• •	X2	B2	· · · ·	X2
F2		X8			





STEP **32**

B3	X4	F2	aetad	X4
----	----	----	--------------	----


HOGYME

x2






- 40 -



PRODUCT ASSEMBLY

STEP 33




41

PRODUCT ASSEMBLY

	F1		X14
--	----	--	-----






PRODUCT ASSEMBLY

STEP 35

13	ΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞΞ	I X/	14	 X2
F2		X8		

The side with holes should be face-up.




43

PRODUCT ASSEMBLY

STEP **36**





44

X2


≣ 5

PRODUCT ASSEMBLY

STEP 37


1:	3	 X2	14
F	2	X4	


PRODUCT ASSEMBLY



Please install by the number order shown in the step 37, or the holes in the roof panel cannot be








PRODUCT ASSEMBLY



Screws on the top panel can't be fixed too tightly in the beginning, and they can only be tightened after all holes are aligned.


STEP **39**

P5		X3	F1	X24
S2	0	X24		



PRODUCT ASSEMBLY

P7		X1	F1	X9
S2	0	X9		




PRODUCT ASSEMBLY


STEP 41

P8		X1	F1		X6
S2	0	X6		-	



P7		X1	F1	X9
S2	0	X9		





PRODUCT ASSEMBLY


STEP 43

P6		X2	F1	X18
S2	0	X18		

(F1 (F1 **2**x **\$**\$2) **2**x (S2) **a**11 (F1) **2**x **2**x **F1**)x6 S2)x6

- 51 ·


PRODUCT ASSEMBLY



PRODUCT ASSEMBLY

STEP 45

P7		X1	F1	X9
S2	0	X9		




- 53 ·

PRODUCT ASSEMBLY

STEP **46**

P8		X1	F1	X6
S2	0	X6		



54

PRODUCT ASSEMBLY


STEP 47

P7		X1	F1		X9
S2	0	X9		-	


PRODUCT ASSEMBLY

STEP **48**

P5		X3	F1	X27
S2	0	X27		




55



PRODUCT ASSEMBLY

STEP **49**

ſ	17	 X2	18	F	X2
ſ	F1	X4	S2	0	X4




- 57 -

PRODUCT ASSEMBLY

STEP **50**

15	F	X2	16		X2
GC	ß	X4	S2	<m()< td=""><td>X10</td></m()<>	X10
S2	0	X6			



- 58 -

PRODUCT ASSEMBLY


STEP 51


19	X2	F1		X1
F2	X2	S2	0	X1

PRODUCT ASSEMBLY

STEP **52**

GE	\bigcirc	X2	F1	X6
S2	0	X6		





- 59 -

PRODUCT ASSEMBLY


STEP **53**

20	X1	D1	X1
F2	X6		


PRODUCT ASSEMBLY

STEP **54**

27	X1	F2		X6
----	----	----	--	----



- 61 -




- 62 -

HOGYME

PRODUCT ASSEMBLY


STEP 55




PRODUCT ASSEMBLY


STEP **56**

20	X1	GD	Ĺ	X2
F2	X10			





- 63 -



PRODUCT ASSEMBLY


STEP **57**

20	X1	D2	X1
F2	X6		


PRODUCT ASSEMBLY

STEP **58**

27		X1	F2	X6
	•			



65



- 66 -

PRODUCT ASSEMBLY


STEP **59**

GB GB X1 F2	X3
-------------	----


PRODUCT ASSEMBLY

STE**P 60**

20	X1	GD	Í.	X2
F2	X10		-	



- 67 -



- 68 -

PRODUCT ASSEMBLY


STEP **61**




PRODUCT ASSEMBLY

STEP **62**





69 -



HOGYME