


HOGYME

User Manual

Instruction for Assembly 8' * 12' Metal Shed



Missing Parts, Quality Problem, Questions on Assembly?
Email: Hogyne.service@gmail.com
Request will be replied in 24 hours.

Model Number: HG61T1296

HOGYME

Assembly Preparation

Owner's Manual

Please check local building codes regarding footings, location and other requirements before beginning construction.

Assembly instructions:

Reviewing all instructions and the appropriate information before you begin, make sure following the step sequence carefully for successful results.

Flooring base:

A good location for the storage building is a square and level area with good drainage. The base is not included in the kit which may need purchase separately or may construct a foundation and anchoring system of your own.

A strong plastic sheet (thickness: at least 150µm) should be placed under the foundation to assist in reducing rising dampness from the soil, thus reducing condensation build up in the shed. Your storage building must be anchored to prevent wind damage. Once secured, it is highly recommended applying silicone along the inside of the base rail to minimize condensation.


Parts and Parts List:

Before you start, separate and identify all the parts and hardware to be sure that you have all the necessary parts for your building (refer to the Parts List Page).

If you find that a part is missing, please notify the seller within one week after receiving the product. Do not attempt to assemble the building if parts are missing because any building left partially assembled may be seriously damaged by light winds.

Tools you need:

(Please tear off the safety protection layer before the assembly, keep the part number label if needed)




Safety must be put in the No. 1 position:

1. Select a dry and calm day for your assembly. Team works (Two or more people) are required during the assembly. It is also recommended to finish the assembly in a day to avoid damage to the product or missing of some small parts.
2. Wearing safety gloves, eye protection and long sleeves during the assembly to prevent injury. Pay attention to the sharp edge of some parts.
3. Children and pets are not allowed entering into the construction site.
4. Never concentrate your total weight on the roof of the building. When using a step ladder make sure that it is safe.


Care & Maintenance:

1. Keep the shed clean with soft cloth, use water if necessary.
2. Keep the door tracks clear of dirt and other stuff that prevent them from sliding easily.
3. Clean the snow with necessary tools to make sure it is safe to enter into.
4. The shed is not made for living but storing stuff.
5. Please add some oil on the top and bottom door sliding channel to make door slides smoothly.

Size:




Area of installation requirement:




PRODUCT ASSEMBLY

TOP2




TOP1





PRODUCT ASSEMBLY


MIDDLE


















DOOR

















UNDER
















Hardware List






PART	NO.	Qty.	Box No.
	G2	4	2/3
	GB	2	2/3
	GC	4	2/3
	GD	4	2/3
	GE	2	2/3
	GF	4	2/3
	F1	551	2/3
	F2	98	2/3
	F3	8	2/3
 For drilling	F4	1	2/3
	S1	188	2/3
	S2	500	2/3
	1	2	3/3
	2	2	3/3
	3L&3R	2	3/3

PART	NO.	Qty.	Box No.
	4L&4R	2	3/3
	5	1	3/3
	6	1	2/3
	7&8	2	3/3
	9&11	4	3/3
	22&23	4	3/3
	10L&10R	2	3/3
	24L&24R	2	3/3
	13&14	8	3/3
	15	2	3/3
	16	2	3/3
	17	2	3/3
	18	2	3/3
	19	2	3/3

HOGYME

PART	NO.	Qty.	Box No.
	20	4	2/3
	21L	2	2/3
	21R	2	2/3
	25L	1	1/3
	25R	1	1/3
	27	2	2/3
	B1&B2	4	3/3
	B3	4	3/3
	P1	2	1/3
	P4B	2	2/3
	P2	2	2/3
	P2A	2	2/3
	P3	20	1/3






HOGYME


PART	NO.	Qty.	Box No.
	P5	8	2/3
	P6	8	2/3
	P7	2	2/3
	D1	1	1/3
	D2	1	1/3

PRODUCT ASSEMBLY

! Check the package contents before getting started !

STEP 1


1		X2	2		X2
4L		X1	4R		X1
F1		X12			



PRODUCT ASSEMBLY


STEP 2


F1		X2
----	---	----



PRODUCT ASSEMBLY




STEP 3


F1		X2
----	---	----



PRODUCT ASSEMBLY



STEP 4

3L		X1	3R		X1
F1		X4			




PRODUCT ASSEMBLY

STEP 5

5		X1	F1		X4
---	---	----	----	---	----






The floor frame must be level and square or holes will not align.
 (Notice: Measure the floor frame diagonally. When the diagonal measurements are equal, the floor frame is square.)




PRODUCT ASSEMBLY

 Make the colored side of the steel plate outward.




STEP 6



P2		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY




STEP 7




P3		X1	F1		X4
S2		X4			



PRODUCT ASSEMBLY




STEP 8



P2A		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY




STEP 9




P3		X1	F1		X4
S2		X4			



PRODUCT ASSEMBLY




STEP 10


P2A		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY

STEP 11

P3		X1	F1		X4
S2		X4			



90°



90°



90°



90°



90°



90°



90°



90°



90°



90°



90°



90°



90°



90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°

90°




90°


90°

90°

PRODUCT ASSEMBLY






STEP 13


P3		X1	F1		X4
S2		X4			




PRODUCT ASSEMBLY

STEP 14



22		X2	23		X2
24L		X1	24R		X1
F1		X3			

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 15




F1		X8	S2		X8
----	---	----	----	---	----


 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 16




9		X1	F1		X4
S2		X4			

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 17

11		X1	F1		X4
S2		X4			

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 18




F1		X8	S2		X8
----	---	----	----	---	----

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 19




11		X1	F1		X4
S2		X4			


 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 20



9		X1	F1		X4
S2		X4			

 Put the side with fewer holes facing up.





PRODUCT ASSEMBLY

STEP 21




F1		X6	S2		X6
----	---	----	----	---	----

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 22




10R		X1	F1		X3
S2		X3			

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 23

10L		X1	F1		X3
S2		X3			







Put the side with fewer holes facing up.



PRODUCT ASSEMBLY

STEP 24

7		X1	8		X1
G2		X4			




PRODUCT ASSEMBLY

STEP 25

6		X1	F1		X2
F4		X1			


The 2 screws fixed in this step need to be removed and reinstalled later in the following steps. There are not pre-drilled holes on part 7 and part 8, but they can be easily fixed with screws F1 or F4.



PRODUCT ASSEMBLY




STEP 26


F1		X8	S2		X6
----	--	----	----	--	----



PRODUCT ASSEMBLY




STEP 27


P3		X6	F1		X72
S2		X72			



PRODUCT ASSEMBLY




STEP 28



P4B		X1	F1		X8
S2		X8			



PRODUCT ASSEMBLY




STEP 29


P3		X6	F1		X72
S2		X72			



PRODUCT ASSEMBLY




STEP 30


P4B		X1	F1		X8
S2		X8			



PRODUCT ASSEMBLY




STEP 31


P3		X3	F1		X36
S2		X36			



PRODUCT ASSEMBLY





STEP 32


P3		X1	F1		X15
S2		X15			



PRODUCT ASSEMBLY





STEP 33


P1		X2	F1		X16
F2		X2	S2		X20



PRODUCT ASSEMBLY

STEP 34



25L		X1	25R		X1
F1		X12	S2		X12



PRODUCT ASSEMBLY

STEP 35



21L		X2	21R		X2
GF		X4	F2		X8



PRODUCT ASSEMBLY

STEP 36



B1		X2	B2		X2
F2		X8			




x2

PRODUCT ASSEMBLY

STEP 37

B3		X4	F2		X4
----	---	----	----	---	----






x2

PRODUCT ASSEMBLY


STEP 38

F1		X14
----	---	-----




PRODUCT ASSEMBLY

STEP 39




F1		X14
----	---	-----

 Remove the 2 screws installed in Step 25 and then do this step.




PRODUCT ASSEMBLY

STEP 40

13		X2	14		X2
F2		X8			



 The side with holes should be face-up.



PRODUCT ASSEMBLY




STEP 41

F2		X8
----	---	----




PRODUCT ASSEMBLY

STEP 42


13		X2	14		X2
F2		X4			




The side with holes should be face-up.




PRODUCT ASSEMBLY


 Please install by the number order shown in the step 42, or the holes in the roof panel cannot be aligned.

STEP 43




F2		X4
----	---	----




PRODUCT ASSEMBLY

 Screws on the top panel can't be fixed too tightly in the beginning, and they can only be tightened after all holes are aligned.




STEP 44


P5		X4	F1		X33
S2		X33			



PRODUCT ASSEMBLY




STEP 47


P6		X4	F1		X33
S2		X33			



PRODUCT ASSEMBLY




STEP 48


P7		X1	F1		X9
S2		X9			



PRODUCT ASSEMBLY





STEP 49



P5		X4	F1		X36
S2		X36			



PRODUCT ASSEMBLY






STEP 50


17		X2	18		X2
F1		X4	S2		X4



PRODUCT ASSEMBLY





STEP 51


15		X2	16		X2
GC		X4	F1		X10
S2		X6			



PRODUCT ASSEMBLY




STEP 52


19		X2	F1		X1
F2		X2	S2		X1



PRODUCT ASSEMBLY




STEP 53


GE		X2	F1		X6
S2		X6			



PRODUCT ASSEMBLY

STEP 54


20		X1	D1		X1
F2		X6			



PRODUCT ASSEMBLY

STEP 55


27		X1	F2		X6
----	--	----	----	--	----



PRODUCT ASSEMBLY

STEP 56



GB		X1	F2		X3
----	--	----	----	--	----



PRODUCT ASSEMBLY

STEP 57


20		X1	GD		X2
F2		X10			



PRODUCT ASSEMBLY

STEP 58


20		X1	D2		X1
F2		X6			



PRODUCT ASSEMBLY

STEP 59


27		X1	F2		X6
----	--	----	----	--	----



PRODUCT ASSEMBLY

STEP 60


GB		X1	F2		X3
----	--	----	----	--	----



PRODUCT ASSEMBLY

STEP 61



20		X1	GD		X2
F2		X10			



PRODUCT ASSEMBLY

STEP 62

F3		X8
----	--	----



PRODUCT ASSEMBLY

STEP 63

